

## РАЗМЕРЫ И ОБОЗНАЧЕНИЯ


### ОПРАВКИ ADMS100



обозначение оправки	составные части оправки		
	оголовка	модуль	ХВОСТОВИК
ADMS100-R025031.02.MT3.C	ADMS100-R025031.02.C	ADMS100-R025031.250.C	ADMS100-R025031.MT3.C
ADMS100-R032039.02.MT4.C	ADMS100-R032039.02.C	ADMS100-R032039.250.C	ADMS100-R032039.MT4.C
ADMS100-R040050.02.MT5.C	ADMS100-R040050.02.C	ADMS100-R040050.250.C	ADMS100-R040050.MT5.C
ADMS100-R051063.02.MT5.C	ADMS100-R051063.02.C	ADMS100-R051063.250.C	ADMS100-R051063.MT5.C
ADMS100-R065080.02.MT5.C	ADMS100-R065080.02.C	ADMS100-R065080.250.C	ADMS100-R065080.MT5.C
ADMS100-R082102.02.MT5.C	ADMS100-R082102.02.C	ADMS100-R082102.250.C	ADMS100-R082102.MT5.C
ADMS100-R105130.02.MT5.C	ADMS100-R105130.02.C	ADMS100-R105130.250.C	ADMS100-R105130.MT5.C

пластины	№ комплекта з/ч
2000-1200...2000-1213	1
2000-1214...2000-1222	2
2000-1223...2000-1234	3
2000-1235...2000-1248	4
2000-1249...2000-1256	5
2000-1257...2000-1266	6
2000-1267...2000-1278	7

### МОДУЛИ К ОПРАВКАМ ДЛЯ ПЕРОВЫХ СВЕРЛ ADMS100



обозначение	D	L	S
ADMS100-R025031.250.C	19	250	17
ADMS100-R032039.250.C	26	250	24
ADMS100-R040050.250.C	30	250	27
ADMS100-R051063.250.C	35	250	32
ADMS100-R065080.250.C	40	250	36
ADMS100-R082102.250.C	45	250	40
ADMS100-R105130.250.C	60	250	54